


FIG.14



VL1500Y E03 E28_014
OIL PUMP/FUEL PUMP

| REF# | PART | #REQ | REMARKS |
|------|-------------------------------|------|---------|
| 1 | PUMP ASSY, OIL 16400-38B10 | 1 | |
| 2 | BOLT 01547-06453 | 1 | |
| 3 | BOLT, OUTER COVER | 1 | |

| | | |
|------|--|---|
| | 01547-06553 | |
| 4 | .BOLT 01547-06653 | 1 |
| 5 | GEAR, OIL PUMP DRIVEN (NT:31) 16331-38B01 | 1 |
| 6 | WASHER (12X20X0.5) 09181-12158 | 1 |
| 7 | PIN 09261-05006 | 1 |
| 8 | CIRCLIP 08331-31126 | 1 |
| 9 | VALVE ASSY, OIL RELIEF 16440-17C20 | 1 |
| 10 | GASKET (16X22X2.0) 09168-16002 | 1 |
| 11-1 | FILTER, ENGINE OIL 16510-03G00-X07 | 1 |
| 11-2 | FILTER, ENGINE OIL 16510-03G00-X07 | 1 |
| 12 | STRAINER, OIL 16520-38B10 | 1 |
| 13 | BOLT 01550-05103 | 4 |
| 14 | HOLDER, OIL STRAINER 16525-38B10 | 1 |
| 15 | BOLT 01550-0625A | 2 |
| 16 | O RING (D:3.1,ID:22.7) 09280-22008 | 1 |
| 17 | PUMP ASSY, FUEL 15100-10F00 | 1 |
| 18 | WASHER, LICENSE 09160-06077 | 2 |
| 19 | SPACER 09180-06263 | 2 |
| 20 | CUSHION 09320-09009 | 2 |
| 21 | BOLT 01500-06207 | 2 |
| 21A | BOLT 09116-06011 | 2 |
| 22 | HOSE, FUEL (PUMP & CARB) 15801-10F00 | 1 |
| 23 | CLIP 09401-11415 | 2 |
| 24 | SPRING 09440-14047 | 2 |
| 25 | CLAMP (L:165) 09407-18402 | 1 |