


FIG.31



VL1500Y E03 E28_031
WIRING HARNESS

REF#	PART	#REQ	REMARKS
1-1	HARNESS, WIRING 36610-10F10	1	
1-2	HARNESS, WIRING 36610-10F90	1	
2-1	.FUSE (10A)	4	

	09481-10501	
2-2	.FUSE (15A) 09481-15501	1
3-1	.CLAMP, SW LEADS 09404-06432	2
3-2	CLAMP (L:95) 09404-06434	2
4	CLAMP (L:90) 09407-11402	2
5-1	.CLAMP, BATTERY CABLE 09407-14403	5
5-2	CLAMP (L:235) 09407-25401	2
5-3	CLAMP (L:165) 09407-18402	6
6	WIRE, HORN LEAD 36852-21E10	1
7	BRACKET, FUSE 36744-10F00	1
8	BOLT 01550-0612A	1
9	.SWITCH ASSY, IGNITION 37110-10F00	1
10	.BOLT, PISTON JET VALVE 07130-0616A	1
11	SWITCH ASSY, STOP LAMP 37740-10F00	1
12	SPRING, STOP LAMP 43139-10F00	1
13	SWITCH ASSY, SIDE STAND 37840-10F00	1
14	SCREW 02142-0620A	2
15	HORN ASSY 38500-10F00	1
16	BOLT 01550-0616A	2
17	CLAMP 09407-03401	2
18	KEY, BLANK 37146-48E00	1