


FIG.31B



VL1500Y E03 E28\_031B  
WIRING HARNESS

REF#	PART	#REQ	REMARKS
1-1	HARNESS, WIRING 36610-10F90	1	
1-2	HARNESS, WIRING 36610-10FB0	1	
2	.FUSE (10A)	4	

	09481-10501		
3-1	.FUSE (15A) 09481-15501	1	(FOR 36610-10F90FOR 36610-10FB0)
4	CLAMP (L:95) 09404-06434	2	
5	CLAMP (L:90) 09407-11402	2	
6-1	.CLAMP, BATTERY CABLE 09407-14403	3	
6-2	CLAMP (L:235) 09407-25401	2	
6-3	CLAMP (L:165) 09407-18402	6	
7	WIRE, HORN LEAD 36852-21E10	1	
8	BRACKET, FUSE 36744-10F00	1	
9	BOLT 01550-0612A	1	
10	LOCK SET 37000-26832	1	
11	.SWITCH ASSY, IGNITION 37110-26F02	1	
12	.BOLT, PISTON JET VALVE 07130-0616A	1	
13	SWITCH ASSY, STOP LAMP 37740-10F00	1	
14	SPRING, STOP LAMP 43139-10F00	1	
15	SWITCH ASSY, SIDE STAND 37840-10F00	1	
16	SCREW 02142-0620A	2	
17	HORN ASSY 38500-10F00	1	
18	BOLT 01550-0616A	2	
19	CLAMP 09407-03401	1	
20	KEY, BLANK 37146-48E00	1	