


FIG.2



VL1500Y E03 E28_002
CYLINDER HEAD (REAR)

REF#	PART	#REQ	REMARKS
1	HEAD ASSY, CYLINDER REAR 11103-10F10	1	
2	.SNAP RING 09381-10004	2	
3	.RING, VALVE GUIDE	1	

	09381-10003	
4	PIN 09206-08001	2
5	BOLT (6X60) 09103-06064	2
6	BOLT (6X55) 09103-06102	2
7	GUIDE, VALVE INTAKE (OS:0.3) 11115-38B70	2
8	GUIDE, VALVE (OS:0.3) 11115-45740	1
9	GASKET, CYLINDER HEAD REAR 11142-10F00	1
10	PIN 04211-13189	2
11	BOLT, SENSOR GUIDE 07120-06123	1
12	GASKET, TENSIONER ADJUSTER 09168-06018	1
13	STUD BOLT (8X30) 09108-08142	1
14	STUD BOLT (M12/8) 09108-08205	1
15-1	NUT 08316-10087	2
15-2	NUT, IDLE GEAR SHAFT 08316-1008A	2
16	WASHER, REAR CUSHION ROD 09160-10060	3
16A	GASKET 09168-10017	1
17	BOLT 09103-08181	1
18	BOLT (10X180) 09103-10178	1
19	BOLT (10X190) 09103-10179	1
19A	BOLT (10X200) 09103-10180	1
20	BOLT (10X215) 09103-10181	1
21	BOLT (6X50) 09103-06101	4
22	BOLT (6X45) 09103-06112	2
24	BOLT (8X268) 09103-08213	2
25	BOLT 01550-0630A	4
26	BOLT 01550-0635A	1
27	WASHER (8.5X24X1.6) 09160-08130	2
28	WASHER, OIL GALLERY EXHAUST 09168-06023	6
29-1	SPARK PLUG, DPR7EA-9 (NGK) 09482-00354	1
29-2	SPARK PLUG, DPR7EA-9 (NGK) 09482-00354	1
29-3	SPARK PLUG (NGK, DPR8EA-9) 09482-00334	1
29-4	SPARK PLUG (ND, X24EPR-U9) 09482-00335	1
29-5	SPARK PLUG, DPR9EA-9 (NGK) 09482-00330	1
29-6	SPARK PLUG, X27EPR-U9 (ND) 09482-00331	1
30	CAP, HEAD COVER LH 11173-10F00	1
31	CAP, HEAD COVER RH 11174-10F00	1
32	CUSHION, HEAD COVER CAP 11273-24B00	2
33	WASHER (6.5X18X1.6) 09160-06084	2
34	WASHER, HEAD COVER CAP LOWER 09160-09016	2
35	CUSHION, HOLDER 09320-09016	2
36	BOLT, HEAD COVER CAP NO.1 01547-06707	1
37	BOLT	1

	01547-06507	
38	SPACER, HEAD COVER CAP NO.1 11179-10F00	1
39	SPACER, HEAD COVER CAP 11179-10F10	1
40	CUSHION, HEAD COVER BOLT 09320-13015	2
41	PLUG, CYLINDER HEAD 09241-30008	1
42	BUSH, HEAD COVER BOLT 09301-08007	2
43	PLUG, WATER GALLERY (22X11) 09248-22004	1
44	PIPE, INTAKE REAR 13102-10F00	1
45	.O RING (D:1.9,ID:40.7) 09280-41007	1
46	BOLT 09119-06092	2
47	CLAMP, CARB 09402-52208	1

(close window)