


FIG.8



VL1500Y E03 E28\_008  
CAM SHAFT/VALVE

REF#	PART	#REQ	REMARKS
1	CAMSHAFT, FRONT 12711-38B00	1	
2	CAMSHAFT, REAR 12713-10F00	1	
3-1	SPROCKET, CAMSHAFT	2	

	12741-38B01	
3-2	SPROCKET, CAMSHAFT 12741-38B01	2
4	WASHER 12747-44000	2
5-1	PIN 04221-05109	2
5-2	PIN 09261-05005	2
6	BOLT (6X12.5) 09111-06027	4
7	ARM, VALVE ROCKER, IN 12840-38B01	2
8	.CHAMBER, ADJUSTER 12863-38B00	4
9	ADJUSTER, VALVE LASH 12860-38B01	6
10	.O RING 12864-38B01	6
11	ARM, VALVE ROCKER FRONT, EX 12850-38B02	2
12	.CHAMBER, ADJUSTER 12863-38B00	2
13	.PIN, DECOMP 12844-38B00	2
14	E RING 08332-11033	2
15	SHAFT, VALVE ROCKER ARM, IN 12861-38B00	2
16	WASHER, WAVE 09164-14012	2
17	WASHER, GEAR SHAFT 09181-14139	2
18	GASKET (16X22X2.0) 09168-16003	2
19	SHAFT, VALVE ROCKER ARM, EX 12871-38B00	2
20	WASHER, WAVE 09164-16003	2
21	WASHER 09160-16033	2
22	PLUG, OIL FILLER 09248-18004	2
23	GASKET, OIL FILLER PLUG 09168-18003	2
24	VALVE, INTAKE 12911-38B00	4
25	VALVE, EXHAUST 12912-38B00	2
26	COTTER, VALVE 12932-24400	8
27	.COTTER, VALVE 12932-82000	4
28	RETAINER 12931-33200	4
29	RETAINER, SPRING, EX 12931-45000	2
30	SPRING SET, VALVE, IN 12920-06B00	4
31	SPRING, VALVE, EX 12922-44110	2
32	SEAT, SPRING 12933-33201	4
33	SEAT, SPRING 12933-45001	2
34	SEAL, VALVE STEM OIL 09289-05015	4
35	OIL SEAL (7X14.4X9) 09289-07002	2

(close window)