


FIG.25



VL1500Y E03 E28_025
ELECTRICAL

REF#	PART	#REQ	REMARKS
1	RELAY ASSY, STARTING MOTOR 31800-21E20	1	
1A	.COVER 31861C47E00J000	1	
1B	.FUSE (30A)	2	

	09481-30101	
2	BOLT, STARTING MOTOR (6X8) 09128-06013	2
3	WIRE, STARTER MOTOR LEAD 33810-10F00	1
4	.CAP, STARTER MOTOR 31861-48B10	1
5	RECTIFIER ASSY 32800-44D10	1
6	SCREW 02142-06253	2
7-1	IGNITER ASSY 32900-10F10	1
7-2	IGNITER ASSY 32900-10F60	1
8	WASHER, THROTTLE LEVER 09160-06066	4
9	SPACER (6.1X8X9.5) 09180-06248	2
10	CUSHION 09320-09009	2
11	SCREW 02142-06303	2
12	NUT 08316-1006A	2
13	COIL, IGNITION FRONT 33420-38B00	1
14	SPACER, IGN COIL REAR 09180-06195	2
15	BOLT 01547-05403	2
16	COIL ASSY, IGNITION FRONT 33420-10F10	1
17	SPACER, IGN COIL REAR 09180-06195	2
18	BOLT 01547-05403	2
19	CAP, SPARK PLUG 33510-38B00	2
20	SEAL, SPARK PLUG CAP (SIDE) 33541-47D00	2
21	SEAL, HIGH TENSION CORD 33542-38B00	2
22	RELAY ASSY, DEF LOCK 38740-31G10	1
23	SOLENOID ASSY, DECOMP 33970-10F00	1
24	STOPPER, DECOMP SOLENOID 33971-10F00	1
25	PLUG, T/M OIL DRAIN 01550-0816A	2
26	CUSHION, DECOMP (8X27X3) 33652-19B00	1
27	CUSHION, DECOMP 33972-31D10	1
28	CABLE, DECOMP FRONT 58900-10F00	1
29	CLAMP (L:235) 09407-25401	1

[\(close window\)](#)