


FIG.49



VL1500Y E03 E28_049
STEERING STEM

REF#	PART	#REQ	REMARKS
1	STEM, STEERING 51410-10F00	1	
2	.BEARING (30X55X17) 09265-30009	1	
3	BOLT, STEM	4	

	51147-10F00	
4	BEARING (25X47X15) 09265-25019	1
5	NUT, STEERING STEM 51631-28000	1
6	SEAL, DUST 51643-40502	1
7	WASHER 51356-24B01	1
8	NUT 51353-24B00	1
9	HEAD, STEERING STEM 51311-10F00	1
10	CAP, HANDLE CLAMP BOLT 09250-06009	4
11	BOLT 07130-08307	4
12	HOLDER, HANDLE UPPER 56211-38A01	2
13	HOLDER, HANDLE LOWER 56221-10F00	2
14	BOLT, STAY 51226-10F00	2
15	CUSHION, HANDLE STAY UPPER 56240-38A42	2
16	CUSHION, HANDLE STAY LOWER 56242-39A12	2
17	WASHER 51354-38A40	2
18	NUT, REAR CUSHION ROD RR 09159-10027	2
19	COVER, FRONT FORK 51515-10F00	1
20	SCREW, FR TURN SIGNAL LAMP 09139-08007	2
21	SCREW (6X12) 09139-06027	2
22	PLUG, T/M OIL DRAIN 01550-0816A	2
23	SCREW (6X12) 09139-06027	2
24	LOCK SET, STEERING 51900-38810	1
25	CASE, KEY 51920-48E00	1