


FIG.29A



VL1500Y E03 E28\_029A  
TURN SIGNAL LAMP

REF#	PART	#REQ	REMARKS
1-1	LAMP ASSY, FRONT TURN SIGNAL R 35601-10F60	1	
1-2	LAMP ASSY, FRONT TURN SIGNAL L 35602-10F60	1	
2	.LENS	2	

	35612-38A30	
3	.GASKET 35613-38A00	2
4	.SCREW 35623-38A01	2
5	.GASKET 35627-43010	4
6	BULB (12V,21/5W) 09471-12128	2
7	SCREW 03211-04253	4
8	SCREW 02142-06107	2
9	STAY, FRONT TURNSIGNAL 35671-10F00	1
10	SCREW (6X12) 09139-06027	1
11	SCREW, FR TURNSIGNAL LAMP 09139-08007	2
12-1	LAMP ASSY, REAR TURNSIGNAL RH 35603-10F50	1
12-2	LAMP ASSY, REAR TURNSIGNAL LH 35604-10F50	1
13	.LENS 35652-38A21	2
14	.GASKET 35613-38A00	2
15	.SCREW 35623-38A01	2
16	.GASKET 35627-43010	4
17	.BULB (12V,21W) 09471-12045	2
18	SCREW 03211-04253	4
19	CUSHION, REAR TURN STAY 35674-10F00	1
20	SCREW 02142-06107	2
21	STAY, REAR TURN SIGNAL 35621-10F00	1
22	BOLT 09116-06115	2
23	.SPACER 09180-06310	2
24	CUSHION 09320-09010	2
25	RELAY, TURNSIGNAL LAMP 38610-03F00	1