


FIG.16



VL1500Y E03 E28_016
2ND AIR

REF#	PART	#REQ	REMARKS
1	PIPE, 2ND AIR FR 18410-10F00	1	
2	PIPE, 2ND AIR RR 18420-10F00	1	

3	GASKET, 2ND AIR PIPE 18441-45C01	2	
4-1	VALVE ASSY, 2ND AIR REED 18450-10F03	1	
4-2	VALVE ASSY, 2ND AIR REED 18450-10F03	1	
5-1	HOSE, 2ND AIR VALVE 18461-10F01	2	
5-2	HOSE, 2ND AIR VALVE 18461-10F01	2	
6	HOSE, 2ND AIR CLEANER 18711-10F00	1	
7	BRACKET 18610-10F00	1	
8	PLATE, HEAT GUARD 18740-10F00	1	
9	COVER ASSY, 2ND AIR 18780-10F00	1	
9A	CUSHION, FRONT 47191-22D00	2	
10	CUSHION 18788-48E00	1	
11	BOLT, REAR 09106-08089	1	
12	CAP, HANDLE BAR BOLT 09250-06011	1	
13	BOLT 01500-06403	3	
14	WASHER (6.5X24X1) 09160-06140	3	
14A	BOLT 09116-06176	3	
15	CUSHION 09320-10014	3	
16	HOSE (P/R RELEASE) 09355-35755-600	1	(MODEL W,L:600->170MODEL X,L:600->185MODEL Y/K1/K2/K3/K4,L:600->190)
17	CUSHION 09320-08013	1	
18	CLIP 09401-13409	4	
19	CLIP 09401-15101	2	
20	BOLT, STUD 01421-06163	4	
21	NUT 08316-1006A	4	
22	BOLT 01550-0616A	2	