


FIG.50



VL1500Y E03 E28_050
FRONT WHEEL

| REF# | PART | #REQ | REMARKS |
|------|---|------|---------|
| 1-1 | WHEEL, FRONT (MT3.50X16) 54111-10F00-12R | 1 | |
| 1-2 | WHEEL, FRONT (MT3.50X16) 54111-10F10-12R | 1 | |
| 2 | SPACER, HUB BEARING | 1 | |

| | | |
|------|--|-----|
| | 54731-10F00 | |
| 3 | BEARING 08133-62037 | 2 |
| 4 | AXLE, FRONT 54711-10F01 | 1 |
| 5 | SPACER, AXLE RH 54740-10F00 | 1 |
| 6 | SPACER, AXLE LH 54740-32C00 | 1 |
| 7 | CAP, FRONT AXLE LH 54792-38B00 | 1 |
| 8 | DISC, FRONT BRAKE RH 59211-10F00 | 1 |
| 9 | BOLT (8X33) 09106-08148 | 5 |
| 10 | TIRE, FRONT (150/80-16 71H) 55110-10F00 | 1 |
| 11 | VALVE ASSY, WHEEL RIM (TR412) 43130-24A00 | 1 |
| 12-1 | BALANCER, WHEEL (10G) 43222-73H10 | 0%3 |
| 12-2 | BALANCER, WHEEL (20G) 43224-73H10 | 0%3 |
| 12-3 | BALANCER, WHEEL (30G) 43226-73H10 | 0%3 |
| 13 | CAP, FRONT AXLE RH 54791-38B01 | 1 |