


FIG.49A



VL1500Y E03 E28_049A
STEERING STEM

REF#	PART	#REQ	REMARKS
1	STEM, STEERING 51410-10F20	1	
2	.SEAL, LOWER 51644-12C00	1	
3	BEARING (30X55X17)	1	

	09267-30010	
4	BOLT, STEM 51147-10F00	4
5	BEARING (25X47X15) 09267-25009	1
6	NUT, STEERING STEM 51631-28000	1
7	SEAL, DUST 51643-40502	1
8	WASHER 51356-24B01	1
9	NUT 51353-24B00	1
10	HEAD, STEERING STEM 51311-10F00	1
11	CAP, HANDLE CLAMP BOLT 09250-06009	4
12	BOLT 07130-08307	4
13	HOLDER, HANDLE UPPER 56211-38A01	2
14	HOLDER, HANDLE LOWER 56221-10F00	2
15	BOLT, STAY 51226-10F00	2
16	CUSHION, HANDLE STAY UPPER 56240-38A42	2
17	CUSHION, HANDLE STAY LOWER 56242-39A12	2
18	WASHER 51354-38A40	2
19	NUT, REAR CUSHION ROD RR 09159-10027	2
20	COVER, FRONT FORK 51515-10F00	1
21	SCREW, FR TURNSIGNAL LAMP 09139-08007	2
22	SCREW (6X12) 09139-06027	2
23	PLUG, T/M OIL DRAIN 01550-0816A	2
24	SCREW (6X12) 09139-06027	2
25	LOCK SET, STEERING 51900-38810	1
26	CASE, KEY 51920-48E00	1