


FIG.31A



VL1500Y E03 E28_031A
WIRING HARNESS

REF#	PART	#REQ	REMARKS
1-1	HARNESS, WIRING 36610-10F90	1	
1-2	HARNESS, WIRING 36610-10F90	1	
1-3	HARNESS, WIRING	1	

	36610-10F90	
2-1	.FUSE (10A) 09481-10501	4
2-2	.FUSE (15A) 09481-15501	1
3-1	.CLAMP, SW LEADS 09404-06432	2
3-2	CLAMP (L:95) 09404-06434	2
4	CLAMP (L:90) 09407-11402	2
5-1	.CLAMP, BATTERY CABLE 09407-14403	3
5-2	CLAMP (L:235) 09407-25401	2
5-3	CLAMP (L:165) 09407-18402	6
6	WIRE, HORN LEAD 36852-21E10	1
7	BRACKET, FUSE 36744-10F00	1
8	BOLT 01550-0612A	1
9-1	LOCK SET 37000-26832	1
9-2	LOCK SET 37000-26832	1
9-3	LOCK SET 37000-26832	1
10-1	.SWITCH ASSY, IGNITION 37110-26F02	1
10-2	.SWITCH ASSY, IGNITION 37110-26F02	1
10-3	.SWITCH ASSY, IGNITION 37110-26F02	1
11	.BOLT, PISTON JET VALVE 07130-0616A	1
12	SWITCH ASSY, STOP LAMP 37740-10F00	1
13	SPRING, STOP LAMP 43139-10F00	1
14	SWITCH ASSY, SIDE STAND 37840-10F00	1
15	SCREW 02142-0620A	2
16	HORN ASSY 38500-10F00	1
17	BOLT 01550-0616A	2
18	CLAMP 09407-03401	1
19	KEY, BLANK 37146-48E00	1